

# **INSTALLATION INSTRUCTIONS**

## **2 PIECE HANDGUARDS YHM-9670, YHM9670-C, YHM-9803 & YHM-9805**

**A competent gunsmith familiar with your firearm should install these hand guards. Failure to install this product correctly voids any warranties of the product and removes any liabilities against the manufacturer. Be certain the firearm is unloaded and always pointing in a safe direction before starting this removal and installation process.**

- (1) Remove your existing plastic forearm panels by retracting the delta ring and lifting the rear of the panels out.
- (2) Install the new forearm panels starting with the top one (3 RAILED) first. Insert the front of the panel into the front cup. Be sure it engages completely and is inserted all the way in as it was designed to fit in snugly to prevent movement once installed.
- (3) Retract the delta ring fully and insert the back of the panel over the barrel nut and make sure the delta ring engages over the back collar.
- (4) Repeat the procedure for the bottom panel.