

INSTALLATION INSTRUCTIONS: PHANTOM COMP FLASH SUPPRESSORS

**YHM-28-5C1 YHM-28-5C2
YHM-3080-5C1 YHM-3080-5C2**

**PHANTOM COMP/BRAKES
YHM-28-5M1 YHM-28-5M2**

ONLY a licensed gunsmith experienced with your model of firearm should install this product. Failure to install this product correctly voids any warranties of the product and removes any liabilities against the manufacturer. Be certain the firearm is unloaded and the muzzle is pointed in a safe direction before starting this removal and installation process.

- (1) Remove any existing muzzle attachment and clean the threads of your barrel.
- (2) Install the supplied crush washer making certain the small-protruded portion of the washer is contacting the flange surface of your barrel.
- (3) Hand-tighten your new muzzle accessory in place.
- (4) Using a $\frac{3}{4}$ " wrench, tighten the suppressor at least $\frac{1}{2}$ turn and continue to turn the suppressor so the middle exhaust port is on top dead center with your sight line.